



Notes

1. The modifiedPLUS® flashing membranes are thermofused to the primed substrate (non-combutable). The granule surfaced cap sheet can be left exposed.
2. Alternatively, use modifiedPLUS® NP180 Tack Sheet as a self-adhered base sheet flashing and thermofuse the granulated cap sheet flashing over.
3. Apply Poly-Tac™ or 910-01 when using thermofusible membranes. For self-adhered modifiedPLUS® NP180 Tack Sheet use Tack Sheet Adhesive 930-38.

790-11 Membrane P.M.R. Assembly

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 05

TYPICAL PARAPET

CONCRETE DECK

HR-8E97



15 Wallsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com